



Preparation installation

1. In case of material using VIVA BOARD
 - 1.1 use purlin, distance 40 cm.
 - 1.2 At every distance of 2.40 meters, double purlin to support Viva Board next sheet.
 - 1.3 Install eaves higher than purlin 12 mm. in case use VIVA BOARD

2. In case of material using OSB BOARD
 - 2.1 Purlin distance 40-41 cm.
 - 2.2 At every distance of 2.44 meters, double purlin to support OSB Board next sheet.
 - 2.3 Install eaves higher than purlin 10 mm. in case use OSB BOARD



Installing shingle roof waterproofing system

1. Install VIVA BOARD + XPS Insulation FOAM on the purlin use Screw end drill #8x2"
2. Install PRIMER surface
3. Install MEMBRANE
4. Install SHINGLE Starter use Staples #1013
5. Install SHINGLE Roof

For more information, please contact
 Mobile 081-912-2823 Ms.Kanlaya Suwan (Dao)
 clearpoints.kanlaya@gmail.com Line ID 0819122823
 Technical support Call : 081-934-4422

<https://www.facebook.com/clearpoints>
www.clear-points.com

